# <u>burster</u>

## Subminiature Load Cell

### Model 8411

Code:8411 ENDelivery:10 weeksWarranty:24 months

CAD data 2D/3D for this sensor: Download directly at www.traceparts.com Info: refer to data sheet 80-CAD-EN



- Very small dimensions
- Robust construction
- Made of stainless steel
- High resonance frequency
- For tensile and compressive forces
- Characteristic curve deviation < 0.5% F.S.</li>

#### Application

The sensors series 8411 have deliberately been given small dimensions, so that they can easily be incorporated into existing structures or fitted into locations where access is difficult. Tensile and compressive forces are introduced to the cylindrical sensor housing through the two threaded bolts. Typical applications for these subminiature load cells include their use as measuring devices in equipment construction in general, in production lines, in measurement and control equipment, test equipment and so forth.

The sensor is to be carefully screwed into place using the threaded bolts. Tools must not be used for assembly.

The force must only be applied centrally, along the center line, and only through the threads. Other fitted parts must not touch the sensor housing; it is recommended that adhesive is applied to the threads. Bending, flexing or torsion forces will cause errors in the measurements and can damage the sensor. To avoid overload during assembly, it is helpful if electrical connections are made to the sensor beforehand and if the measurement on the display is watched during the process.

#### Description

The forces to be measured are applied centrally to the load cell through the two threaded pins. One covering surface of the cylindrical sensor housing is implemented as a measuring element, with the strain gauge being applied to its inner side.

Under the influence of force, the full bridge circuit is unbalanced, and an output signal proportional to the force is generated.

A rigid compensation circuit board, 7 mm wide and 70 mm long, is located in the connecting cable to the sensor about 900 mm from the sensor body. This contains a resistor network for balancing the bridge and for temperature compensation. Removing the circuit board, or changing the cable length, will disturb the sensor's calibration figures.

The strong, rigid design leads to high natural frequencies up to 160 kHz as a result, which is beneficial for dynamic measurements. The active side is the thread next to the cable.

Order Code	Measurement Range	Dimensions [mm]			Thread	Resonance Frequency	Charac- teristic Nominal	Torsional Moment max.			
		øD	Н	В	L	М	øΚ	Т	[kHz]	[mV/V]	[Nm]
8411-2,5	0 2.5 N	12.7	6.6	7.4	5.1	2.2	1.9	M3 x 0.5	3.0	15	0.45
8411-5	0 5 N	12.7	6.6	7.4	5.1	2.2	1.9	M3 x 0.5	4.0	15	0.45
8411-10	0 10 N	12.7	6.6	7.4	5.1	2.2	1.9	M3 x 0.5	7.0	2	0.45
8411-20	0 20 N	12.7	6.6	7.4	5.1	2.2	1.9	M3 x 0.5	11.0	2	0.45
8411-50	0 50 N	12.7	6.6	7.4	5.1	2.2	1.9	M3 x 0.5	18.0	2	0.45
8411-100	0 100 N	12.7	6,6	7.4	5.1	2.2	1.9	M3 x 0.5	26.0	2	0.45
8411-200	0 200 N	12.7	6.6	7.4	5.1	2.2	1.9	M3 x 0.5	40.0	2	0.45
8411-500	0 500 N	12.7	6.6	7.4	5.1	2.2	1.9	M3 x 0.5	67.0	2	0.45
8411-1000	0 1000 N	19.1	9.7	-	7.9	4.6	2.5	M6 x 1.0	85.0	2	2.25
8411-2000	0 2000 N	19.1	9.7	-	7.9	4.6	2.5	M6 x 1.0	98.0	2	2.25
8411-5000	0 5000 N	19.1	9.7	-	7.9	4.6	2.5	M6 x 1.0	167.0	2	2.25

#### Electrical values

Bridge resistance (full bridge):

J	· · · · · · · · · · · · · · · · · · ·			
measuring range	≤05N	semiconductor st	train gauge	
			500 $\Omega$ , nominal	
measuring range	$\geq 0 \dots 10 N$	foil strain gauge	350 $\Omega$ , nominal	
Reference excitation	voltage:		5 V DC	
Nominal sensitivity:			refer to table	
Insulation resistance:		> 5000	) M $\Omega$ at 50 V DC	
Shunt resistor:			59 kΩ ±0.1 %	
The bridge output voltage, caused by a shunt resistor of value is given in the calibration protocol.				

#### Environmental conditions

Range of operating temperature:	- 55 °C + 120 °C
Nominal temperature range:	+ 15 °C + 70 °C
Influence of temperature on zero:	$\leq \pm$ 0.02 % F.S./K
Influence of temperature on sensitivity:	$\leq$ + 0.02 % Rdg./K
Mechanical values	
Relative error:	< ± 0.5 % F.S.
Relative hysteresis error:	< ± 0.5 % F.S.
Relative variation:	< ± 0.1 % F.S.

Kind of measurement: tensile and compressive forces, calibration in tensile direction (preferential direction). On operation against preferential direction, estimate a changed characteristic.

Deflection:		13 µm 38 µm
Maximum static load:		150 % of nominal load
Dynamic load:	recommended possible	70 % of nominal load 100 % of nominal load
Material:	stainless steel 17-	-4 PH (similar to 1.4542)

Electrical connection:

High flexible, color coded, teflon isolated wire with open end for soldering. Length 1.5 m. Steep circuit board, width approximately 7 mm, length 70 mm, for bridge leveling, calibration and temperature compensation, 0.7 m away from the sensor body. Cable shield between sensor and circuit board.

Protection clas	SS:	acc. to EN 60529	IP54
Wiring code:	red	excitation voltage	positive
	black	excitation voltage	negative
	green	signal output	negative
	white	signal output	positive


Dimensions: refer to table and dimensional drawing Ranges  $\geq 0$  ... 1000 N have a steep cable cover at the sensor body length 7.6 mm, ø 2.5 mm.

Weight: measuring range < 0 ... 500 bar without cable approx. 7 g measuring range > 0 ...1000 bar without cable approx. 19 g

#### **Mounting Instructions**

The force to be measured must be applied centrally, without transverse force, through the external thread. It is essential that the sensor is not exposed to clamping forces that act sideways, as this can cause errors in the measurement or damage to the sensor.

In order to ensure that the load cell is securely fastened in its proper position, adhesive can be applied to the thread. Suitable design, such as the provision of guides for mounted parts, must be used to ensure that buckling does not occur when compression forces are applied. Take care when handling and fitting to ensure that the point where the cable emerges and the sensor connection cable are not subjected to unacceptably large tensile or bending forces. Proper strain relief may need to be provided. **Dimensional drawing model 8411** 



Ranges  $\geq 0 \dots 1000$  N without a collar at the housing, near the thread.

## The CAD drawing (3D/2D) for this sensor can be imported online directly into your CAD system.

Download via www.burster.com or directly at www.traceparts.com. For further information about the burster traceparts cooperation refer to data sheet 80-CAD-EN.

#### **Order Information**

Accessory	
measuring range 0 20 N	Model 8411-20
Subminiature load cell	

Connector

12 pin, suitable to all burster desktop devices Model 9941 9 pin, suitable to model 9235 and DIGIFORCE<sup>®</sup> model 9310 Model 9900-V209

Installation of a connector to the sensor cable for primary use: in preferential direction (positive measuring signal for tensile forces) Order Code: 99004

only for connection to SENSORMASTER model 9163 desktop unit Order Code: 99002

against preferential direction (positive measuring signal for compressive forces) Order Code: 99007

only for connection to SENSORMASTER model 9163 desktop unit Order Code: 99008

Analysis units, amplifiers and controllers like amplifier module

model 9243, digital indicator model 9180 or

DIGIFORCE® model 9306 please refer to section 9 of the catalog

#### Option

#### Manufacturer Calibration Certificate (WKS)

Calibration of the load cell, with or without evaluation electronics. Calculation of charges with basic costs and additional costs per calibration point. Please state the requested calibration points. Standard is a calibration with 11 points in 20 % increments up and down the whole measurement range. The calibration is done for tensile and compressive forces.

 Technical SUNSTAR自动化-http://www.sensor-ic.com/TEL:0755-83376489\_FAX:0755-83376482\_E\_MA+L:\$459-22243630C900\_x64588

 Latest updates of data sheet always under www.burster.com
 Talstr. 1-5 · D-76593 Gernsbach · www.burster.com