

Model 2102 Small Flanged Reaction Torque Sensor

DESCRIPTION

Model 2102 small flanged reaction torque sensor is designed for installation between test pieces such as motors, switches, axles, or shafts and their mounting plate. These models operate and are calibrated in both directions. Nickel-plated alloy steel construction enhances durability in harsh, industrial environments. These models have no moving parts and utilize four bonded strain gages on a special machined portion of the transducer to achieve a maximum non-linearity of 0.1% over a wide dynamic range. Typical applications include tire braking, motor dynamometers, friction-skid testing, and twist measurement. 50 in-lb to 1000 in-lb capacities.

FEATURES

- 50 in-lb to 1000 in-lb capacities
- 0.1 % non-linearity and hysteresis
- Reaction measurements designed to eliminate speed limitations
- Reduced friction error
- No maintenance of slip rings, bearings, or brushes
- Compact, "low mass" physical style

Safety considerations: It would be unsafe to operate Honeywell torque sensors and load cells beyond static overload or ultimate extraneous load limits as defined in the glossary of terms or, when applicable, higher than maximum speed. When in doubt, consult factory. Honeywell is not responsible for any property damage or personal injury which may result because of the misapplication of the transducer.

Model 2102

PERFORMANCE SPECIFICATIONS

Characteristic	Measure			
Torque range	50, 100, 200, 500, 1000 lb-in			
Non-linearity	±0.1 % of rated output			
Hysteresis	±0.1 % of rated output			
Repeatability	±0.05 % of rated output			
Output @ rated capacity	2.5 mV/V (nominal)			


ENVIRONMENTAL SPECIFICATIONS

Characteristic	Measure				
Temperature, operating	-54 °C to 93 °C [-65 °F to 200 °F]				
Temperature, compensated	21 °C to 77 °C [70 °F to 170 °F]				
Temperature effect, zero	±0.002 %/of rated output °F				
Temperature effect, output	±0.002 %/of reading °F				


ELECTRICAL SPECIFICATIONS

Characteristic	Measure			
Excitation (maximum)	20 Vdc or Vac RMS			
Insulation resistance	> 5000 mOhm @ 50 Vdc			
Bridge resistance	350 ohm (nominal)			
Number of bridges	1			
Zero balance	±1.0 % of rated output			

TYPICAL SYSTEM DIAGRAM



LOAD CARRYING CAPACITY



W - weight
W x S - overhung moment
S - distance to W
Do not exceed moment (W x S) or shear (W), whichever value is attained first
P = thrust

Honeywell

Small Flanged Reaction Torque Sensor


MECHANICAL SPECIFICATIONS


Model	Capacity Nm [Ib-in]	Overload Nm [lb-in]	Torsional stiff- ness Nm/rad [lb-in/rad]	Max. overhung moment WxS Nm [lb-in]	Max. shear W N [lb]	Max. thrust P N [lb]	
2102-50	5 [50]	7.5 [75]	266 [2350]	5.50 [50]	57.82 [13]	886 [200]	
2102-100	10 [100]	20 [150]	760 [6725]	11 [100]	88.96 [20]	1236 [280]	
2102-200	20 [200]	30 [300]	2124 [18800]	22 [200]	115.65 [26]	1760 [400]	
2102-500	55 [500]	85 [750]	8315 [73600]	27.50 [250]	2224 [500]	2200 [500]	
2102-1K	115 [1000]	170 [1500]	14348 [127000]	56 [500]	3558 [800]	2900 [660]	

Torsional stiffness given for sensor less shaft extension(s).

MOUNTING DIMENSIONS

A	B	C	D	E	F	G	H	K	L
cm [in]	cm [in]	cm [in]	cm [in]	cm [in]	cm [in]	cm [in]	cm [in]	cm [in]	cm [in]
7,62 [3]	6,03 [2.38]	5,08 [2]	4,130 [1.626]	0,36 [0.14]	0,640 [0.252]	0,79 [0.31]	45° [45°]	3,18 [1.25]	3,18 [1.25]





For reference only

SUNSTAR传感与控制 http://www.sensor-ic.com/ TEL:0755-83376549 FAX:0755-83376182 E-MAIL:szss200163.com Small Flanged Reaction Torque Sensor

Warranty. Honeywell warrants goods of its manufacture as being free of defective materials and faulty workmanship. Honeywell's standard product warranty applies unless agreed to otherwise by Honeywell in writing; please refer to your order acknowledgement or consult your local sales office for specific warranty details. If warranted goods are returned to Honeywell during the period of coverage, Honeywell will repair or replace, at its option, without charge those items it finds defective. The foregoing is buyer's sole remedy and is in lieu of all warranties, expressed or implied, including those of merchantability and fitness for a particular purpose. In no event shall Honeywell be liable for consequential, special, or indirect damages.

While we provide application assistance personally, through our literature and the Honeywell web site, it is up to the customer to determine the suitability of the product in the application.

WARNING PERSONAL INJURY

• DO NOT USE these products as safety or emergency stop devices or in any other application where failure of the product could result in personal injury.

Failure to comply with these instructions could result in death or serious injury.

WARNING MISUSE OF DOCUMENTATION

- The information presented in this datasheet is for reference only. DO NOT USE this document as product installation information.
- Complete installation, operation and maintenance information is provided in the instructions supplied with each product.

Failure to comply with these instructions could result in death or serious injury.

Find out more

Honeywell serves its customers through a worldwide network of sales offices, representatives and distributors. For application assistance, current specifications, pricing or name of the nearest Authorized Distributor, contact your local sales office. To learn more about Honeywell's test and measurement products, call **+1-614-850-5000**, visit **www.honeywell.com/sensotec,** or e-mail inquiries to **info.tm@honeywell.com**

Sensing and Control Honeywell 1985 Douglas Drive North Golden Valley, MN 55422

Honeywell

008797-2-EN IL50 GLO January 2010 Copyright © 2010 Honeywell International Inc. All rights reserved.

SUNSTAR自动化 http://www.sensor-ic.com/ TEL: 0755-83376489 FAX:0755-83376182 E-MAIL:szss20@163.com

www.honeywell.com