

# Glossary

## A

### ▣ Activation energy

This is the energy required for a substance to perform a reaction. In the Arrhenius equation for calculating the speed of a chemical reaction, activation energy is used as an indicator for expressing how easily a chemical reaction occurs. The Arrhenius equation is used to calculate the service life of an LED, etc. The activation energy of LED degradation is obtained from the failure rate under several temperature conditions.

### ▣ Afterpulse

Afterpulses are pseudo signal pulses following the true signal output pulse. In an MPPC, this indicates a phenomenon that produces pulses other than signals when the generated carriers are trapped by crystal defects and then released at a certain time delay. Afterpulses can cause detection errors the same as from crosstalk and dark pulses. The lower the temperature, the higher the probability that carriers may be trapped by crystal defects, so afterpulses will increase.

### ▣ Amorphous

Noncrystalline state having no definite form. For example, when a liquid or gaseous semiconductor is cooled and solidified so rapidly that no crystals are formed, it becomes amorphous. In this state, the crystal structure has a short-distance order but does not have a long-distance order, and a tail level appears at the band gap edge, making the optical characteristics different from those of monocrystalline or polycrystalline materials.

### ▣ Anisotropic etching

An etching process in which the etching speed in a particular direction is different from that in other directions. For example, when a (100) silicon substrate is alkaline etched, V-grooves are formed due to the fact that the etching speed on the (100) plane is faster than that on the (111) plane. Etching in which the etching speed is the same in all directions is called isotropic

etching.

### ▣ Anodic bonding

When the flat surface of glass containing alkali metal is attached to the flat surface of silicon and heated while a voltage is being applied, an electrostatic attractive force is generated at the interface between the glass and silicon. Anodic bonding is the bonding technique that makes use of this phenomenon. During anodic bonding, the silicon side is used as the anode.

### ▣ Arrhenius equation

The equation (see below) describing the temperature dependence of chemical/physical reaction speeds, proposed by S. A. Arrhenius (Sweden) in 1889. This equation is used to calculate the expected life of a component when a major cause of degradation of the component is probably temperature.

$$K = A \times \exp(-E_a / k T)$$

K : reaction speed  
 A : constant  
 E<sub>a</sub>: activation energy [eV]  
 k : Boltzmann's constant [eV/K]  
 T : absolute temperature [K]

### ▣ ASE (amplified spontaneous emission)


An optical amplifier amplifies signal light by induction radiation. However, it emits energy little by little even under conditions where no signal light is input. This is optical amplifier spontaneous emission and is referred to as ASE. This ASE is noise and degrades characteristics.

## B

### ▣ Band gap energy

In a semiconductor, insulator, or metal, electrons surrounding the nucleus are present in energy levels with a certain width. In semiconductors or insulators, among the energy bands where electrons exist, the highest energy band filled with electrons at absolute zero degrees is called the valence band, and the

energy band with no electrons is called the conduction band. The energy range in the band gap (forbidden band) between the valence band and the conduction band is called the band gap energy. In metals, there is no band gap because the valence band and conduction band overlap each other.



► Bias T

A circuit used to apply a DC bias to a device. This circuit is capable of applying a DC bias while maintaining an impedance match and is therefore needed when using a high-speed device.

► Bi-phase signal

An encoding method of modulating signals so that “0” signals or “1” signals will not occur in consecutive 3 bits or more. Compared to NRZ signals, bi-phase signals have two-fold redundancy and the bandwidth usage efficiency is 50%. As one example, a 25 Mbps bi-phase signal is equivalent to an NRZ signal of 50 Mbps. Bi-phase signals offer the advantage that they can extract clock components by using a simple circuit. Other encoding methods similar to bi-phase signals include CMI (coded mark inversion) and Manchester encoding.

► Bit error rate

This is one measure for evaluating the transmission quality of digital transmissions. It indicates the probability that the transmitted codes may be incorrectly identified. The bit error rate is intimately related to the S/N, but there are cases where the bit error rate is not determined just by the S/N.

► Blooming

A phenomenon in which the photoelectrically converted signal charge in an image sensor exceeds a certain level and spills over into adjacent pixels or transfer region other than photodiodes (in IT type CCDs). In CCDs, the spill-out charge appears in the image as a vertical stripe occurring from the light incident position the same as with “smear.” To prevent blooming, some means for discharging excess charge should be implemented. In CCDs, this blooming is suppressed by using a vertical/horizontal anti-blooming or clocking method.

► Bragg diffraction

A coherent, strong reflection that occurs at a particular angle at which the phases are matched by multiple surface reflections

when monochromatic light strikes a light-scattering material with a cyclically arranged structure. This technique is utilized to fabricate resonators in semiconductor lasers.

► Breakdown voltage

As the reverse voltage applied to a PN junction is raised, an abrupt increase in reverse current occurs at a certain voltage. This voltage is called the breakdown voltage. As a guide for convenience when evaluating our Si APD, the voltage that produces a reverse current of 100  $\mu$ A is specified as the breakdown voltage.

► Bump bonding

A technology for fabricating bumps (metal protrusions such as solders) on a semiconductor wafer. Bump bonding is used for three-dimensional mounting, and the fine-pitch bumps make devices smaller and more sophisticated.

C

► C-band, L-band

Wavelength band classification used for optical communication. The spectral range for C-band and L-band spans from 1530 nm to 1625 nm. Other wavelength band names depending on the spectral range are used as shown below.

- L-band: 1565 nm to 1625 nm
- C-band: 1530 nm to 1565 nm
- S-band: 1460 nm to 1530 nm
- E-band: 1360 nm to 1460 nm
- O-band: 1260 nm to 1360 nm

► CDR (clock and data recovery)

A device for recovering a clock and data. Data output from a CDR is not exactly the same as the input data, and is synchronized with the timing of the recovered clock.

► CDS (correlated double sampling)

A signal processing method most commonly used for reducing readout noise in a CCD. The CCD signal output detected with an FDA contains kTC noise originating from the detection node capacitance. The kTC noise is also referred to as thermal noise and is always generated by reset operation in a charge-to-voltage converter device like a CCD. The kTC noise in the output can be reduced by using CDS which detects the difference in voltage levels before and after the signal charge flows in the detection node. CDS is also used to reduce noise in CMOS image sensors.

### ▣ Compton scattering

The phenomenon in which X-rays and gamma rays, etc. are scattered and part of their energy is lost when they collide with particles (electrons, etc.). This phenomenon is known as indicating particle properties of X-rays, etc.

### ▣ Crosstalk

A phenomenon in which an electrical signal generated in an element by an incident light signal leaks out into adjacent elements. In an MPPC, a carrier excited in an APD pixel by an incident photon is multiplied in the avalanche process. During this process, photons different from the incident photon might be generated. If these photons are detected by other APD pixels, then the MPPC output will be higher than the number of photons that actually entered the MPPC. This phenomenon is thought to be one cause of crosstalk in the MPPC.

### ▣ Cut-off frequency

The frequency at which the output of a device decreases by 3 dB from the constant output at lower frequencies. The relation between the cut-off frequency ( $f_c$ ) and the rise time ( $t_r$ ) is approximately expressed by the equation below.

$$t_r [s] = \frac{0.35}{f_c [\text{Hz}]}$$

## D

### ▣ Dark count

In an MPPC or APD used in Geiger mode, thermally generated dark current carriers are amplified and output as dark pulses. These dark pulses are one cause of detection errors. The number of dark pulses per second is the dark count [unit: cps (counts per second)]. Although increasing the reverse voltage improves detection efficiency, it also increases the dark count. The dark count can be reduced by lowering the temperature.

### ▣ Dark current

A small current which flows when a reverse voltage is applied to a photodiode even in a dark state. This current is called the dark current. Noise resulting from dark current becomes dominant when a reverse voltage is applied to photodiodes (PIN photodiodes, etc.).

### ▣ DBR (distributed Bragg reflector)

This is a reflector containing a diffraction grating having a cycle of  $\lambda/2n$  ( $\lambda$ : wavelength in vacuum,  $n$ : refractive index of medium)

formed outside the light emission region in light-emitting devices such as LEDs and semiconductor lasers in order to selectively reflect the light of wavelength  $\lambda$ . In VCSEL (vertical cavity surface emitting lasers), forming DBR layers as the upper and lower layers of the light-emitting layer at an appropriate distance causes resonance only at a specific wavelength, so the laser beam can be emitted in the direction perpendicular to the surface. In some LEDs, a DBR layer is formed underneath the light-emitting layer to increase the light level.

### ▣ Diffraction grating

An optical element designed to obtain a spectrum by making use of light diffraction. Reflective diffraction gratings usually have a great number of grooves formed in their surfaces and utilize diffraction images created by interference with light beams reflected from the grating surface.

### ▣ Double-heterostructure

A structure where a low-band-gap energy semiconductor material is sandwiched between high-band-gap energy semiconductor materials. Since carriers are confined in the low-band-gap region (emission region), the carrier density increases to allow efficient electron-hole recombination.

## E

### ▣ E detector, $\Delta E$ detector

The E detector is a detector with a thickness enough to cover the range of high energy particles. It is designed for detecting the total energy of a particle. The  $\Delta E$  detector in contrast is made thin enough to allow the particles being detected to pass through it so that the specific energy loss in the particle can be detected. A combination of a  $\Delta E$  detector and E detector is called the  $\Delta E$ -E detector and is an effective means of identifying particles.

### ▣ EDFA (erbium-doped fiber amplifier)

A device that directly amplifies light using a quartz-based optical fiber with an erbium-doped core. Light is amplified in the optical fiber by induced radiation. When a weak light signal enters the EDFA, light amplification occurs at the same wavelength as the signal light. The EDFA is widely used as an optical amplifier for long-distance optical fiber communication in the 1.55  $\mu\text{m}$  band.

### ▣ Ethernet

Ethernet is one of several computer network standards. This

was devised by Xerox and DEC (currently part of Hewlett Packard) and standardized by the IEEE 802.3 committee. This is the most common LAN (local area network) standard and is widely used in offices and homes all over the world.

▶ eV (electron volt)

Energy acquired by an electron when it is accelerated through a potential difference of 1 V in a vacuum. This is generally used as a unit to express the energy of elementary particles, atomic nuclei, atoms, and molecules, etc.

$$1 \text{ eV} = 1.602 \times 10^{-19} \text{ J}$$

▶ Excitation

In semiconductors, excitation refers to the process of raising electrons from a low-energy valence band to the higher-energy conduction band. If electrons are excited by heat, this process is called thermal excitation. If an electron is excited by light, then this process is called photoexcitation. Light absorption by a photodiode is photoexcitation.

▶ Extinction ratio

The ratio of the minimum value to the maximum value in the light power that varies during intensity modulation of light waves. In digital optical communications, this is defined as the ratio of the light power for transferring logic “1” to the light power for transferring logic “0.” This extinction ratio is expressed in either linear ratio, dB, or %.

[Extinction ratio in digital optical communications]

$$\text{Extinction ratio (linear ratio)} = I(1)/I(0)$$

$$\text{Extinction ratio [dB]} = 10 \log_{10} \{\text{extinction ratio (linear ratio)}\}$$

$$\text{Extinction ratio [\%]} = I(0)/I(1) \times 100$$

I(1): light power for transferring logic “1”  
I(0): light power for transferring logic “0”

▶ Eye diagram

This is a superimposed display of all waveforms for possible encoded strings, used to perform a comprehensive evaluation of the waveform distortion of the transmitted encoded pulses. This is also called the eye pattern.

**F**

▶ Fano factor

Average number (J) of electron-hole pairs generated in a crystal

by incident radiation is expressed by the following equation:

$$J = \frac{E}{\epsilon}$$

E: energy of radiation  
ε: average energy required to generate an electron-hole pair

In this case, the standard deviation (σ: Fano noise) which represents statistical fluctuations in the number of electron-hole pairs is expressed by the following equation:

$$\sigma = \sqrt{FJ}$$

F in this equation is a coefficient for correcting deviations from the Poisson distribution and is called the Fano factor.

▶ FDA (floating diffusion amplifier)

A low-noise readout method most commonly used for a CCD output section. HAMAMATSU CCDs use this FDA.

▶ Fill factor

This is the ratio of the “photodiode area excluding the wiring section, etc.” to the area of the pixel.

▶ Flip-chip bonding

A technique for bonding a chip with bumps (metal protrusions such as solders) attached to the electrodes on the upper surface of the chip, by placing the chip upside down onto a package or another chip to make electrical connections. Chip-on-chip mounting allows much smaller assembly.

▶ FTTH (fiber to the home)

This is an ongoing plan to build a high-speed, broadband data communication environment by using optical fibers as telephone subscriber lines extending from telephone stations to each home. FTTH is considered the final goal to replace all subscriber lines with optical fibers. Steps to reach that goal are called as follows depending on the stage of progress: FTTZ (fiber to the zone), FTTC/FTTP (fiber to the curb/fiber to the pedestal), and FTTA/FTTB/FTTO (fiber to the apartment/fiber to the building/fiber to the office).

▶ FWHM (full width at half maximum)

This is used to describe the width of a normal distribution (Gaussian distribution). FWHM is the full width at half (1/2) maximum of a normal distribution.

## G

### Gain

When carriers (electrons or holes) are excited by incident photons, the gain is expressed as the ratio of the number of carriers that are output after being multiplied, to the number of the excited carriers.

In the case of an APD, the gain  $M$  is defined as the ratio of the photocurrent  $I_p$  multiplied by application of a high reverse voltage to the photocurrent  $I_{p0}$  generated at a low reverse voltage not causing a multiplication.

$$M = I_p/I_{p0}$$

In the case of an MPPC, the gain  $M$  is the ratio of the charge of one output pulse divided by the charge of one electron.

$$M = \text{Charge of one output pulse}/q$$

$q$ : electron charge

### Gain bandwidth product (GB product)

This is the product of the gain and bandwidth, and is used as a measure for indicating characteristics of an amplifier element.

### Geiger discharge

When an APD is operated at a reverse voltage higher than the breakdown voltage, even very low incident light causes a discharge in the APD due to the high electrical field. This phenomenon is called Geiger discharge.

### Geiger mode

Operation mode in which an APD is operated at a reverse voltage higher than the breakdown voltage. Geiger mode operation makes it possible to detect single photons.

### Group delay characteristic

This is a characteristic that indicates the time delay of the output waveform versus an input waveform. This can be obtained by differentiating the phase characteristic with respect to the frequency. If the phase characteristic is linear, then the group delay becomes a constant value, allowing signal transmission without any distortion.

## H

### Hysteresis

A phenomenon in which the output level of a device measured

while the input level is increased does not equal the output level measured while the input level is decreased, even if at the same input level. Because of this phenomenon, noise within the hysteresis width does not cause chattering. Hysteresis circuits used in a comparator make use of this effect by feeding back part of the output to the non-inverted input terminal.

## I

### I<sup>2</sup>C (inter-integrated circuit)

A serial interface developed by Philips Electronics. The I<sup>2</sup>C, pronounced “I-squared-C” or “I-two-C,” allows information transfer between ICs by using two signal lines that are SCL (serial clock) and SDA (serial data) lines. The I<sup>2</sup>C is used in electronic appliances, cell phones, digital cameras, and audio equipment, for example, when connecting a low-speed (several hundred kilohertz) peripheral device to microcontrollers.

### Integration capacitance

Because signal processing is not easy in current-output type NMOS linear image sensors, their output is converted to a voltage output that has low noise and is easier to process by using an inverted input op amp circuit with a feedback capacitance ( $C_f$ ) added. This feedback capacitance is called the integration capacitance. Periodically resetting the integration capacitance provides a voltage output ( $V = Q/C_f$ ) converted from an electric charge ( $Q$ ). The smaller the integration capacitance, the larger the output voltage will be.

### Integration time

In image sensor operation, the electric charge generated by light entering in a given time is accumulated and collected to create a signal. The length of this time during which light enters the image sensor is called the integration time or accumulation time. This is usually in the order of milliseconds (ms) but may extend to several hours in cooled type image sensors. In image sensors with a shutter function, the integration time can be set to the order of microseconds ( $\mu\text{s}$ ).

### Interelectrode resistance

This is the resistance between the opposing electrodes of a PSD when it is in a dark state. The interelectrode resistance is an important factor that determines the response speed, position resolution, and saturation photocurrent. The interelectrode resistance is measured with 0.1 V applied across the output terminals of the opposing electrodes while the common electrode is left open. When measuring the interelectrode resistance of a two-dimensional PSD, the output terminals other than the output

terminals of the opposing electrodes are also left open.

▣ Ionization rate

In an APD or other similar devices, electron-hole pairs are generated when the accelerated electrons and holes collide with the lattice while moving. The ionization rate is the number of these generated electron-hole pairs per unit distance. Units are in “per centimeter.”

L

▣ Lattice constant

In a crystal, atoms are arrayed uniformly to form a crystal lattice. The lattice constant is a measure that defines the size of the unit lattice, which is the minimum unit of a crystal lattice.

▣ Linearity

When light strikes a photodiode, a photocurrent is generated in proportion to the light level. This proportional relationship between the photocurrent and light level is called the linearity. If the incident light level becomes higher than a certain level, then the linearity begins to deviate, causing the photocurrent in the photodiode to saturate. The light level causing saturation depends on the photodiode structure and also varies according to the load resistance, reverse voltage, and the size of the incident light spot.

M

▣ MBE (molecular beam epitaxy)

An epitaxial growth technology for forming a thin-film crystal on a heated substrate crystal by supplying molecular beams of crystal-constituent elements, which are created by evaporating each element from separate cells in an ultra-high vacuum.

▣ MCA (multichannel analyzer)

An instrument that displays the heights of multiple input pulses as a histogram.

▣ MEMS (micro-electro-mechanical systems)

MEMS is a system for integrating electronic circuits with microactuators, micromechanisms, and microsensors, etc. fabricated using fine processing technology.

▣ Microfocus X-ray source

This is an X-ray source with a very small focal spot on the order of micrometers. Microfocus X-ray sources allow capturing clear, sharp magnified X-ray images since edge blur is suppressed even when magnified.

▣ Minimum sensitivity

The minimum light input power required to acquire bit error rates within a certain level. The minimum sensitivity differs depending on the transmission bit rate, the required bit error rate, the type of pseudo-random codes used for measurement, and the extinction ratio, etc.

▣ MOCVD (metal organic chemical vapor deposition)

An epitaxial growth technology for forming a thin-film crystal on a heated substrate crystal by thermally decomposing and chemically reacting an organic metal supplied in the form of vapor, which is solid or liquid at normal temperatures and pressures.

▣ MOEMS (micro-opto-electro-mechanical systems)

Optics systems using MEMS technology. Also called optical MEMS.

▣ MOST (Media Oriented Systems Transport)

An in-vehicle network standard mainly used in European vehicles. This is a ring type network using POF (plastic optical fibers), and its internode communication speeds are 25 Mbps and 150 Mbps. Besides in-vehicle applications, MOST is used for interphone networks in airports, etc.

▣ MPP (multi-pinned phase) operation

MPP is an operation mode in which all CCD channels under the MOS structure gates constituting the CCD electrodes are reversed. This mode is also called reverse operation and reduces the dark current because it drastically suppresses the generation of thermally excited electrons at the silicon-silicon dioxide interface.

▣ Multimode fiber

An optical fiber for transmitting light in multiple transverse mode (electromagnetic field distribution). Multimode fibers are not suitable for long-distance transmissions because the transmitted waveform is distorted due to differences in the signal light arrival time depending on the mode (modal dispersion). Compared to single-mode fibers, the core diameter is large so that connecting to a light emitter is easy. However,

condensing a light beam onto a light receiver element for high-speed communication is difficult because the element must have a small light receiving area.

## N

### ▣ NEP (noise equivalent power)

NEP is the incident light level equivalent to the noise level of a device. In other words, it is the light level required to obtain a signal-to-noise ratio (S/N) of 1. We define the NEP value at the peak sensitivity wavelength ( $\lambda_p$ ). Since the noise level is proportional to the square root of the frequency bandwidth, the bandwidth is normalized to 1 Hz.

$$\text{NEP [W/Hz}^{1/2}] = \frac{\text{Noise current [A/Hz}^{1/2}]}{\text{Photo sensitivity [A/W] at } \lambda_p}$$

### ▣ NGN (next generation network)

This is a next-generation information communication network utilizing IP (internet protocol) technology, and is intended to deliver multimedia services by merging fixed-line phones, mobile phones, data communication, etc. In addition to the reliability and stability provided by conventional telephone networks, NGN will also offer the same flexibility and economical efficiency as IP networks.

## O

### ▣ Open circuit voltage

A photovoltaic voltage developed in a photodiode when the load resistance is infinite. This open circuit voltage depends on the light level but is nearly constant except for fairly low light levels.

### ▣ Open-loop gain

This is the gain of an operational amplifier with no feedback applied, and represents the ratio of the output voltage to the input voltage. Units are in dB.

### ▣ Optical return loss (ORL)

The ratio of the reflected return light to the incident light. If the reflected return light level is high, the laser diode oscillation on the transmit side will become unstable causing relative intensity noise to increase. The reflected return light level must therefore be minimized. As solutions for this problem in receptacle type modules, an optical isolator, or a ferrule called a “stub” (component with the fiber insertion side polished for physical

contact and the device side polished slantwise) is often inserted in the optical path to minimize the optical return loss.

### ▣ Overload

This is the maximum light input power of a photosensor device. When more than a given amount of light enters a photosensor device, the photodiode or amplifier becomes saturated. This disturbs the output waveform, making it impossible to receive optical signal correctly.

## P

### ▣ p.e. (photon equivalent)

This represents the detection level per photon. A 1 p.e. pulse, for example, is equivalent to the pulse obtained when one photon is detected.

### ▣ Passive alignment

Precise mechanical positioning for coupling alignment between two or more optical elements during optical module assembly. Since the positioning of optical elements usually requires accuracy ranging from submicrons to several microns, highly precise metalization patterns and V-grooves formed by semiconductor process technology are utilized as the positioning reference.

In contrast to passive alignment, active alignment performs the positioning of optical modules or fibers while making the optical modules emit light by simulating actual operation (for instance, operating a laser diode to emit light) and monitoring the emitted light in order to obtain the required characteristics of the optical modules.

### ▣ Phosphor screen

A scintillator in the form of a thin sheet. This is usually fabricated by depositing scintillator material on a support substrate and covering it with protective film.

### ▣ Photo sensitivity

The ratio of photocurrent expressed in amperes (A) or output voltage expressed in volts (V) to the incident light level expressed in watts (W). Photo sensitivity is represented as an absolute sensitivity (A/W or V/W) or as a relative sensitivity (%) to the peak wavelength sensitivity normalized to 100. We usually define the spectral response range as the range in which the relative sensitivity is higher than 5% or 10% of the peak sensitivity.

▶ Photoconductive detector

A photosensor which increases its electric conductivity when illuminated with light. An external power supply is needed to operate a photoconductive detector. Photoconductive detectors include MCT (HgCdTe), PbS, PbSe, etc.

▶ Photoelectric effect

A phenomenon in which a substance absorbs light and generates free electrons.

▶ Photon detection efficiency (PDE)

This is a measure of what percent of the incident photons were detected. PDE is expressed by the following equation. The avalanche probability (Pa) becomes larger as the reverse voltage is increased.

$$PDE = QE \times fg \times Pa$$

QE: quantum efficiency  
fg : geometric factor  
Pa : avalanche probability

▶ Photovoltaic detector

A semiconductor photosensor generating an electrical current or voltage when light is illuminated on its PN junction. It is capable of operating without power supplied from an external source. Photovoltaic detectors include Si, InGaAs, GaAsP, GaAs, InAs, InSb, etc.

▶ Position detection error

When a light spot irradiates onto a PSD and the resulting current extracted from each output terminal of the PSD is equal, the incident position of the light spot is called the electrical center of the PSD. By considering this electrical center as the origin, the position detection error is defined as the difference between the position at which the light spot is actually incident on the PSD and the position calculated from the photocurrents. We measure the position detection error under the following conditions:

- Light source :  $\lambda=890$  nm
- Light spot size:  $\phi 200$   $\mu$ m
- Photocurrent : 10  $\mu$ A

▶ Position resolution

The minimum detectable displacement of a light spot incident on the photosensitive surface of a PSD, expressed as a distance on the photosensitive surface of the PSD. This position resolution is determined by the S/N, which is calculated by: PSD resistance length  $\times$  noise/signal. We define the position

resolution calculated based on root-mean-square (rms) noise measured under the following conditions:

- Interelectrode resistance: See characteristic table in our datasheets.
- Photocurrent : 1  $\mu$ A
- Frequency bandwidth: 1 kHz
- Equivalent input voltage noise of circuit: 1  $\mu$ V

▶ Power dissipation

The maximum power consumption allowed for a device, calculated from the upper temperature limit of the package and chip. In most cases, this is determined by heat-vulnerable components included in the device. Using a coefficient called “derating” makes it possible to calculate the absolute maximum rating for the power dissipation at the temperature at which the device will actually be used. For example, if a power dissipation of 500 mW is defined as the absolute maximum rating at 25 °C and the derating is 5 mW/°C, then the absolute maximum rating at 85 °C will be: 500 mW - 5 mW/°C  $\times$  (85 °C - 25 °C) = 200 mW.

▶ Propagation delay time

The time required for a signal to travel from the transmitted point to the received point. This term generally indicates the total delay time in the circuit and optical elements, and the delay time in a medium (optical fiber, etc.). The propagation delay time that changes is termed the jitter or wander. Jitter is the fluctuation in propagation delay time that occurs in a short period of time and mainly results from noise. Wander is a long-term fluctuation chiefly caused by thermal factors.

▶ Pseudo-random pattern

An encoded string that is seemingly irregular (not truly irregular) and is used to measure bit error rates and eye patterns. In commonly used pseudo-random patterns, the event probability between 0 and 1 is equal so that a pseudo-random pattern can be relatively easily generated by a circuit that uses a shift register and feedback.

Q

▶ Quantum efficiency

This is the number of electrons or holes that can be extracted as photocurrent divided by the number of incident photons. It is commonly expressed in percent (%). The quantum efficiency QE and photo sensitivity S (unit: A/W) have the following relationship at a given wavelength (unit: nm).



$$QE = \frac{S \times 1240}{\lambda} \times 100 \text{ [%]}$$

### ▣ Quenching

Quenching means extinction or rapid cooling. In an APD operated in Geiger mode, quenching is a technique to stop Geiger discharge by reducing the reverse voltage below the breakdown voltage.

## R

### ▣ Reach-through structure

A structure (example:  $N^+$ -P- $\pi$ -P $^+$  layer) whose impurity concentration is not uniform, and is formed in a region near the PN junction boundary in an APD. The  $\pi$ -layer serves as the light absorption region and carriers generated here are multiplied in the P-layer. The APD is used with a high reverse voltage applied so that the  $\pi$ -layer is depleted (reach-through) in order to enhance the speed. This structure is therefore called the reach-through type.

### ▣ Rise time

The rise time is the time required for the output to rise from 10% to 90% of the maximum output value (steady-state value) in response to input of step-function light.

## S

### ▣ Scintillator

A material that emits light when exposed to radiation such as X-rays. Scintillators are divided into inorganic and organic scintillators. Well-known inorganic scintillators are crystals or powder of CsI (cesium iodide) doped with a small amount of activator such as Tl (thallium) to enhance the emission efficiency. Organic scintillators include naphthalene, anthracene, plastic, liquid scintillator, and lumogen. The lumogen is a material that emits light in response to UV rays, and is therefore sometimes coated on front-illuminated CCDs having no UV sensitivity.

### ▣ Short circuit current

This is the output current that flows in a photodiode when load resistance is zero. This is called “white light sensitivity” to differentiate it from the spectral response, and is measured with light from a standard tungsten lamp at 2856 K distribution temperature (color temperature). Our product catalog lists the

short circuit current measured under an illuminance of 100 lx.

### ▣ Shunt resistance

This is the voltage/current ratio of a photodiode operated in the vicinity of 0 V. In our product catalog, the shunt resistance is specified by the following equation, where the dark current ( $I_D$ ) is a value measured at a reverse voltage of 10 mV.

$$R_{sh} [\Omega] = \frac{0.01 \text{ [V]}}{I_D \text{ [A]}}$$

Noise generated from the shunt resistance becomes dominant in applications where a reverse voltage is not applied to the photodiode.

### ▣ Single-mode fiber

An optical fiber designed to transmit light in the single transverse mode (electromagnetic field distribution). Single-mode fibers have low transmission loss and are not affected by modal dispersion, making them suitable for long-distance transmission. However, they require precise core alignment when connecting to a light emitter since their core diameter is small.

### ▣ Smear

In image sensors, smear is a phenomenon where a signal charge generated by intense input light leaks to the adjacent pixels or CCD transfer region and causes the original signal to become smeared (blurred). In contrast to “blooming” that occurs following saturation, smears occur even before saturation. Smears tend to occur from light at longer wavelengths rather than light at shorter wavelengths.

### ▣ SOA (semiconductor optical amplifier)

An optical amplifier using a semiconductor. The structure is very similar to a Fabry-Perot laser diode but is designed not to cause reflection at the edge. SOA enables amplification over a wide spectral range and requires fewer components than EDFA, which makes the amplifier device smaller and reduces power consumption.

### ▣ SONET/SDH

These are international standards for high-speed digital communication methods using optical fibers. SONET (Synchronous Optical Network) is a North American standard specifications established by ANSI (American National Standards Institute) based on technology developed by Bellcore Technologies (now Telcordia Technologies). SDH (Synchronous Digital Hierarchy) is an internationally standardized interface

by ITU (International Telecommunication Union) based on SONET. Although differing on some minor points, SONET and SDH can be considered as nearly the same standard and allow interconnections with each other. SONET is well-known in North America, while SDH is mainly used in Europe.

▣ Space charge effect

When light incident on a photosensor is blocked, the carrier distribution in the depletion layer is disturbed. The carriers are then drawn to the electrodes and generate an electric field in the depletion layer in the direction opposite to the applied bias voltage. This phenomenon is referred to as the space charge effect and might degrade the response characteristics (fall time) when the incident light level is high.

▣ Spatial resolution

The ability of an image sensor to faithfully capture the details of an object. MTF (modulation transfer function) is usually used to evaluate the resolution of an image sensor. When an object with a sine-wave brightness distribution is imaged, the MTF indicates how the sine-wave brightness contrast varies with the spatial frequency. The spatial frequency is the number of times that a sine wave is repeated per unit length. Since the active area of a CCD consists of discrete pixels, CCDs have a limiting resolution determined by the Nyquist limit based on the discrete sampling theorem. For example, when a black-and-white pattern is viewed with a CCD, the difference between the black and white signal levels decreases as the pattern becomes finer, and finally reaches a point at which the pattern can no longer be resolved. The ideal MTF is expressed as follows:  $\text{sinc}^* \{(\pi \times f) / (2 \times f_n)\}$  (f: spatial frequency,  $f_n$ : spatial Nyquist frequency). However, because of the difficulty in creating an optical sine wave, a rectangular-wave response test chart is generally used instead. In this case, the spatial frequency response is called the CTF (contrast transfer function).

\* sinc: Fourier transform of an ideal rectangular function

▣ Spectral response

The relation (photoelectric sensitivity) between the incident light level and resulting photocurrent differs depending on the wavelength of the incident light. This relation between the photoelectric sensitivity and wavelength is referred to as the spectral response characteristic and is expressed in terms of photo sensitivity or quantum efficiency.

▣ Stealth dicing

Stealth dicing is a new dicing method developed by HAMAMATSU. It uses a laser beam to form a modification layer inside a wafer and cut the wafer into chips with high quality. Since light that

transmits into the material is used, no thermal damage occurs on the wafer surface. Stealth dicing does not produce any cutting loss, so the chip yield per wafer can be increased to the maximum. There is absolutely no contamination such as from flying debris which is unavoidable in conventional dicing techniques, and stealth dicing is a completely dry process because no cleaning water is required.

▣ Synchrotron radiation

Intense light that is generated when electrons or positrons are accelerated up to near the speed of light and bent in magnetic fields. Synchrotron radiation covers a broad spectral range from infrared light through X-rays. This light is more than a hundred-million times brighter than light emitted from ordinary X-ray generators. Synchrotron radiation applications are being studied for a wider range of fields including medicine, physics, and chemistry.

T

▣ TAC (time-to-amplitude converter)

An instrument that outputs the time difference between two pulse signals as a pulse amplitude (height).

▣ Terahertz wave

Electromagnetic waves at frequencies around 1 THz (wavelength: 300  $\mu\text{m}$ ). Terahertz waves transmit through paper, wood, and plastic but do not transmit through metal and water. The terahertz band is called the fingerprint region of substances, and their applications are recently being developed along with progress made from basic research.

▣ Terminal capacitance

In a photodiode, the PN junction can be considered as a type of capacitor. This capacitance is termed the junction capacitance and is an important parameter in determining the response speed. In current-to-voltage conversion circuits using an op amp, the junction capacitance might cause gain peaking. At HAMAMATSU, we specify the terminal capacitance including this junction capacitance plus the package stray capacitance.

▣ Thermistor

A thermally sensitive resistor that greatly changes its electrical resistance as the temperature changes. Thermistors are used for temperature sensing.

### ▶ Thermoelectric cooling element

When an electric current flows through the junction of two dissimilar electric conductors, heat absorption (or heat generation) occurs on one side while heat generation (or heat absorption) occurs on the other side. Thermoelectric cooling elements make use of this effect (known as Peltier effect). Reversing the direction of the electric current reverses the relation between the heat absorption and generation.

### ▶ Tiling

An arrangement of two or more photosensors in a tile configuration to have a wider active area. Also called “edge-to-edge butted.”

### ▶ Tracking detector (vertex detector)

A detector mainly used in elementary particle energy physics experiments for the purpose of tracking the traveling direction and decay processes of secondary particles generated as a result of high energy particle collisions. Tracking detectors are installed at positions surrounding the point where the particles collide.

### ▶ Transition frequency

This originally meant the frequency at which the current gain ( $h_{fe}$ ) of an emitter-grounded transistor is 1, but now indicates the frequency at which the gain of an amplifying element becomes 1.

### ▶ Tunable laser

A laser whose oscillation wavelength can be altered within a specific wavelength range. Tunable lasers are used as light sources for multiple-wavelength transmission systems.

## V

### ▶ VCSEL (vertical cavity surface emitting laser)

Semiconductor lasers usually resonate light in a direction parallel to the substrate surface and emit the light in that direction. In VCSEL however, light resonates in a direction perpendicular to the substrate surface and is emitted perpendicular to the substrate. Therefore, the resonant cavity can be formed and laser characteristics can be tested without cleaving the substrate during the manufacturing process. This fact makes VCSEL suitable for high volume production. Compared to edge-emitting lasers, VCSEL can be manufactured at a lower cost and can be easily arrayed in two dimensions. Other features include low threshold current, high-speed modulation at low current, and small temperature dependence.

### ▶ VICS (Vehicle Information and Communication System)

An information communication system in Japan that transmits road traffic information such as traffic jams, road construction, road regulations, and time required to reach destination to in-car navigation equipment, etc. Information from optical beacons installed on major trunk roads and from radio-wave beacons installed along highways as well as specific wide-area information by FM multiplex broadcasting are transmitted to the cars in real time.

## W

### ▶ WDM (wavelength division multiplexing)

WDM is a method for multiplexing multiple data on single-core optical fiber cable by changing the wavelength of the carrier wave. There are two modes depending on the multiplexed density: DWDM (dense wavelength division multiplexing) and CWDM (coarse wavelength division multiplexing). DWDM typically uses eight or more wavelengths in the 1.55  $\mu\text{m}$  band (some use the 1.3 or 1.6  $\mu\text{m}$  band) that are densely arranged at wavelength intervals from 0.4 to 3.2 nm. In contrast, CWDM uses two to eight wavelengths spaced at wavelength intervals ranging from 20 to several hundred nanometers.



深圳商斯达实业**专用电路与单片机部**是专业开发、设计、生产、代理、经销专用电路(ASIC)

和单片机配套产品, 温度、湿度、语音、报警、计时、计步、测速、调光、游戏、新特优等专用芯片和模组; 专用电路、微控制器、DSP、语音系统开发、设计、测试、仿真工具, 为消费电子、通信、家电、防盗报警厂家提供专业服务。产品主要有: 1、温度计电路、体温计电路、湿度计电路、时钟温湿度计电路、计时钟控电路、计步运动表电路、测速电路、调光电路、游戏电路、防盗报警电路、遥控电路、钟表电路、闪灯电路、计数电路、语音电路等专用芯片和模组, 为三资企业、外贸出口企业提供完整配套服务; 2、带LED闪烁电路、声效电路、玩具钢琴电路、音乐音效电路、灯串电路、风扇控制电路、计算器电路、万年历电路、汇率转换电路、玩具声光电路、遥控编解码电路、红外线遥控电路、无线遥控电路及配件、语音录放电路、圣诞灯电路、热释电控制器(人体感应)电路等专用芯片和配套模组。

更多产品请看本公司产品专用销售网站:

商斯达中国传感器科技信息网: <http://www.sensor-ic.com/>

商斯达工控安防网: <http://www.pc-ps.net/>

商斯达电子 元器件网: <http://www.sunstare.com/>

商斯达微波光电产品网: [HTTP://www.rfoe.net/](http://www.rfoe.net/)

商斯达消费电子产品网: [//www.icasic.com/](http://www.icasic.com/)

商斯达实业科技产品网: [//www.sunstars.cn/](http://www.sunstars.cn/)

传感器销售热线:

地址: 深圳市福田区福华路福庆街鸿图大厦 1602 室

电话: 0755-83387016 83387030 83398389 83600266

传真: 0755-83376182 (0) 13902971329 MSN: [SUNS8888@hotmail.com](mailto:SUNS8888@hotmail.com)

邮编: 518033 E-mail: [szss20@163.com](mailto:szss20@163.com) QQ: 195847376

深圳赛格展销部: 深圳华强北路赛格电子市场 2583 号 电话: 0755-83665529 25059422

技术支持: 0755-83394033 13501568376

欢迎索取免费详细资料、设计指南和光盘; 产品凡多, 未能尽录, 欢迎来电查询。

北京分公司: 北京海淀区知春路 132 号中发电子大厦 3097 号

TEL: 010-81159046 82615020 13501189838 FAX: 010-62543996

上海分公司: 上海市北京东路 668 号上海赛格电子市场 2B35 号

TEL: 021-28311762 56703037 13701955389 FAX: 021-56703037

西安分公司: 西安高新开发区 20 所(中国电子科技集团导航技术研究所)

西安劳动南路 88 号电子商城二楼 D23 号

TEL: 029-81022619 13072977981 FAX: 029-88789382